3-5. Using the hands-free system (for cellular phone)

Hands-free system (for cellular phone)

The hands-free system is a function that allows you to use your mobile phone without touching it.

This system supports Bluetooth[®] mobile phones. Bluetooth[®] is a wireless data system that allows the mobile phone to wirelessly connect to the hands-free system and outgoing/incoming calls.

- ► Touch screen operation with navigation system

 Owners of models equipped with a navigation system should refer to the "Navigation System Owner's Manual".
- ► Touch screen operation without navigation system

n Telephone switch



- Sending/Receiving/ "Telephone" screen display (when stopped)
- 2 End call

n Microphone (type A)



The person you are speaking to can be heard from the driver's side speaker.

n Microphone (type B)



The person you are speaking to can be heard from the driver's side speaker.

To use the hands-free system, you must register your Bluetooth[®] phone in the system. (\rightarrow P. 418)

Status display

You can check such indicators as signal strength and battery charge on the "Telephone" screen.



- Connection status
- Battery charge
- 3 Call area
- 4 Signal strength

Indicators	Conditions
Connection status	Blue: Good Yellow: Bad : Not connected
Battery charge	: Full : Low : Empty
Call area	"Rm": Roaming area "Hm": Home area
Signal strength	Yill: Good Y: Bad Y: Not connected

${\it n}\$ When using the hands-free system

- $1\,$ The audio system and voice guidance are muted when making a call.
- 1 If both parties speak at the same time, it may be difficult to hear.
- 1 If the received call volume is overly loud, an echo may be heard.
- $1\,\,$ Try to face toward the microphone as much as possible when speaking.
- 1 In the following circumstances, it may be difficult to hear the other party:
 - · When driving on unpaved roads
 - · When driving at high speeds
 - · If a window is open
 - If the air-conditioning is blowing directly on the microphone
 - If the air-conditioning is set to high

n Conditions under which the system will not operate

- 1 If using a mobile phone that does not support Bluetooth®
- 1 If the mobile phone is switched off
- 1 If you are outside service range
- 1 If the mobile phone is not connected
- 1 If the mobile phone's battery is low

n Bluetooth® antenna

The antenna is built into the display. If the mobile phone is behind the seat or in the console box, or touching or covered by metal objects, connection status may deteriorate.

n Battery charge/Signal status

This display may not correspond exactly with the mobile phone itself.

n About Bluetooth®



Bluetooth is a registered trademark of Bluetooth SIG. Inc.

n Compatible models

Compatible with HFP (Hands Free Profile) Ver. 1.0 and OPP (Object Push Profile) Ver. 1.1.

If your cellular phone does not support HFP, you cannot enter the Bluetooth $^{\circledR}$ phone. If your cellular phone supports OPP alone, you cannot use the Bluetooth $^{\circledR}$ phone.

n Certification for the hands-free system

FCC ID: BABBT007A BABBT008A IC ID: 2024B-BT007A MADE IN JAPAN

This device complies with Part 15 of the FCC Rules and RSS-Gen of IC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

A CAUTION

n FCC WARNING

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Radio Frequency Exposure. This equipment complies with FCC radiation exposure limits set forth for uncontrolled equipment and meets the FCC radio frequency (RF) Exposure Guidelines in Supplement C to OET65. This equipment has very low levels of RF energy that it deemed to comply without maximum permissive exposure evaluation (MPE). But it is desirable that it should be installed and operated with at least 7.9 in. (20 cm) and more between the radiator and person's body (excluding extremities: hands, wrists, feet and legs).

This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

n Caution while driving

Do not use the mobile phone or connect the Bluetooth[®] system.


⚠ NOTICE

n When leaving the vehicle

Do not leave your mobile phone in the vehicle. The inside of the vehicle may become hot, causing damage to the phone.

3-5. Using the hands-free system (for cellular phone)

Using the Bluetooth® phone



Registering a Bluetooth® phone

You can register up to 6 phones in the system.





Touch 🔐



Touch Register.



Input the passkey displayed on the screen into your phone.

If the message "Bluetooth* connection successful" is displayed, registration is complete.

If the message "Bluetooth* connection failed. Please check the "Passkey" and the settings of the telephone" is displayed, start again from the beginning.

*: Bluetooth is a registered trademark of Bluetooth SIG. Inc.

Bluetooth® phone connection

There are two connection methods available—automatic and manual.



STEP 2 Touch on the "Information" screen.

STEP 3 Touch settings on the "Telephone" screen.

STEP 4 Choose one of the following methods.



Automatic connection

If the "ENGINE START STOP" switch is in the ACCESSORY or IGNITION ON mode, the system will automatically connect to the Bluetooth[®] phone. Touching "Auto Connect" will turn it on/off.

Manual connection

If automatic connection fails or is turned off, connection must be made manually.

If the message "Bluetooth* connection successful" is displayed, connection is complete.

*: Bluetooth is a registered trademark of Bluetooth SIG. Inc.

n Reconnecting to the Bluetooth® phone

If the system cannot connect due to poor signal strength with the "ENGINE START STOP" switch in the ACCESSORY or IGNITION ON mode, the system will automatically attempt to reconnect.

If the phone is turned off, the system will not attempt to reconnect. In this case, connection must be made manually, or the phone must be re-selected.

Making a call

Once the Bluetooth[®] phone is registered, you can make a call using the following procedure:

n Dialing



STEP 2 Touch on the "Information" screen.



Input the phone number.


To delete the inputted phone number, touch



n Dialing from the phone book

You can dial a number from the phone book data imported from your mobile phone. Up to 1000 entries may be stored in the phone book. $(\rightarrow P. 441)$





Choose the desired name to call from the list.




Choose the number and then touch or press on the steering wheel.

n Dialing from history


You can make a call from past dialed numbers or received calls. Up to 5 numbers are stored, with the last recent number being deleted to make room for a new number.





Choose the number to call from the list.

To choose a number from the incoming calls history, touch and choose a number to call.




Touch or press on the steering wheel.

n Calling using speed dial

You can make a call using numbers registered from the phone book and call history. $(\rightarrow P. 434)$



STEP 2 Touch on the "Information" screen.






Choose the desired number to make a call.

To change the page, touch


n Calling using voice recognition

Using voice recognition, you can call by name from the "Phone Book" screen, call by number from the "Telephone" screen, and send tones from the "Call" screen. $(\rightarrow P. 429)$



Talk switch

1 Calling by name from the "Phone Book" screen



Pull 6.

Following the system guidance, wait until a beep and then say the desired name.

If there are multiple entries for the same name, Next will be displayed.

To select the next candidate, touch Next .

STEP 3 Following the system guidance, pull .

Following the system guidance, wait until a beep and then say "Dial".

1 Calling by number from the "Telephone" screen



- STEP 2 Following the system guidance, wait until a beep and then say the desired number.
- STEP 3 Following the system guidance, pull 😿 .
- Following the system guidance, wait until a beep and then say "Dial".
- 1 Sending tones from the "Call" screen



- STEP 2 Following the system guidance, wait until a beep and then say the desired number.
- STEP 3 Following the system guidance, pull 🔣 .
- Following the system guidance, wait until a beep and then say "Yes".

n Made/received call history list

- If you make a call to or receive a call from a number registered in the phone book, the name is displayed in the call history.
- 1 If you make multiple calls to the same number, only the last call made is displayed in the made calls history.
- 1 sis displayed to the left of phone number for unanswered calls.
- 1 s displayed to the left of the phone number for refused calls.
- 1 Calls where the number is unavailable, such as public telephones, are not stored in the call history.

n When driving


- 1 The functions "Dialing", "Dialing from the phone book", and "Dialing from history" are unavailable.
- I If you press on the steering wheel, the "Speed Dial" screen is displayed. At this time, phone numbers will not be displayed. Choose from the names displayed to make a call.

n International calls

You may not be able to make international calls, depending on the mobile phone in use.

n To display the voice recognition command list





n To display the voice recognition operating guide





n To cancel voice recognition

- 1 Pull and hold 😽
- 1 Press on the steering wheel.
- 1 Touch Cancel (excluding command verification)

n When using voice recognition

Use correct commands and speak clearly, otherwise the system may not correctly recognize the command. Wind or other noises may also cause the system not to recognize the desired command.

Receiving a call

When a call is received, the following screen is displayed together with a sound.



Touch or press on the steering wheel.

n To refuse a call

Touch or press on the steering wheel.

$\, n \,$ To adjust the received call volume

Touch or . You can also adjust the volume using the steering switches.

n International calls

Received international calls may not be displayed correctly, depending on the mobile phone in use.

Speaking on the phone

The following screen is displayed when speaking on the phone.



- n To adjust the received call volume
 - Touch or . You can also adjust the volume using the steering switches.
- n To prevent the other party from hearing your voice Touch Mute.
- n Inputting key tones

When using phone services such as an answering service or a bank, you can store phone numbers and code numbers in the phone book.





Input the number.

- If repeated tone symbols* are stored in the phone book, and are displayed on the right side of the screen.
- *: Repeated tone symbols are symbols or numbers displayed as p or w, that come after the phone number.

(e.g. 056133p0123w#1])

STEP 3 Confirm the number displayed on the screen, and touch send.

If you touch send, operation is completed without making a call.

n To transfer a call

Touch Transfer Call .

n To hang up

Touch or press on the steering wheel.

n Transferring calls

- 1 It is not possible to transfer from hands-free to the mobile phone while driving.
- 1 If you transfer from the mobile phone to hands-free, the hands-free screen will be displayed, and you can operate the system using the screen.
- 1 Transfer method and operation may vary according to the mobile phone used.
- 1 For operation of the mobile phone in use, see the phone's manual.

n To send a tone by speed tone

Touch o-9 and touch choose the desired number from the speed tone list displayed.

n While driving

Key input is unavailable.

3-5. Using the hands-free system (for cellular phone) Setting the hands-free system (for cellular phone)

You can speed dial, register in and edit the phone book, and set the Bluetooth $^{\circledR}$ phone.




To display the screen shown above, press , touch on the "Information" screen, and touch settings on the "Telephone" screen.

Registering/Deleting a speed dial item


n Registering a speed dial item

You can register a number from the phone book or the call history. Up to 17 entries may be stored.






Touch Register in the "Speed Dial" section of the "Speed Dial Settings" screen.



Select the data to be registered.



Select the number to be registered.



Touch the desired switch.

The last dialed number will be registered in position 6.

n Deleting a speed dial item



STEP 2 Touch on the "Information" screen.

STEP 3 Touch settings on the "Telephone" screen.

STEP 4 Touch on the "Settings" screen.

STEP 5 Touch Delete in the "Speed Dial" section of the "Speed Dial Settings" screen.

STEP 6 Select the data to be deleted, and a confirmation message will be displayed.

STEP 7 If everything is correct, touch Yes

n To delete all speed dial items

Follow the steps for "Deleting a speed dial item" until "STEP 5". In the "Speed Dial" section of the "Speed Dial Settings" screen, touch Deal A. A confirmation message will be displayed. If everything is correct, touch Yes.....

Registering/Editing/Deleting a speed tone

n Registering a speed tone

You can register up to 6 items.





Register in the "Speed Touch Tone" section.



Input the desired name and touch OK



A-Z, À-Ý: Letter input 0-9: Number/Symbol input Space : Space : Backspace



Input the number and touch OK.



Touch the desired switch.

n Editing a speed tone




STEP 2 Touch on the "Information" screen.

STEP 3 Touch Settings on the "Telephone" screen.

STEP 4 Touch on the "Settings" screen.

STEP 5 Touch in the "Speed Tone" section of the "Speed Dial Settings" screen.




n To delete all speed tone data

STEP 7 If everything is correct, touch 1

Follow the steps for "Deleting a speed tone" until "STEP 5". In the "Speed Tone" section, touch confirmation message will be displayed. If everything is correct, touch section.

Setting the volume



n Adaptive volume control

When traveling at 50 mph (80 km/h) or more, the system automatically raises the volume one level.

OK

If the vehicle's speed drops to 43 mph (70 km/h), the volume will return to its original level.


You can turn this function on/off by touching Adaptive Volume Control

n To return to the default volume settings

Touch Default, and then Yes.

Changing the screen settings

The following settings can be changed:



- 1 "Incoming Call Display"
 - The incoming call screen settings can be changed.
- 1 "Auto Answer"

When a call is received, the system automatically switches to the talking screen after the set period of time, meaning you can speak without pressing anything.

1 "Show Bluetooth* connection status at startup"

You can set the system to show the status confirmation display when connecting.

*: Bluetooth is a registered trademark of Bluetooth SIG. Inc.

n "Incoming Call Display" settings

STEP 1 Press .

STEP 2 Touch on the "Information" screen.

STEP 3 Touch settings on the "Telephone" screen.

STEP 4 Touch on the "Settings" screen.

STEP 5 Select the desired switch.

Full: The hands-free screen is displayed when a call is received, and you can operate the system from that screen.

: A message is displayed at the top of the screen, and you can only operate the system with the steering switches.

n "Auto Answer" settings

STEP 1 Press

STEP 2 Touch on the "Information" screen.

STEP 3 Touch settings on the "Telephone" screen.

STEP 4 Touch on the "Settings" screen.

Settings" screen.

STEP 6 Set the wait time using \bigcirc and \bigcirc . (1 - 60 seconds)

n "Show Bluetooth" connection status at startup" settings

STEP 1 Press .

STEP 2 Touch on the "Information" screen.

STEP 3 Touch settings on the "Telephone" screen.

STEP 4 Touch on the "Settings" screen.

STEP 5 Touch ON / OFF in the "Show Bluetooth* connection status at startup" section of the "Screen Settings" screen.

n To set the screen settings to default


Touch Default, and then Yes.

^{*:} Bluetooth is a registered trademark of Bluetooth SIG. Inc.

Phone book settings

Up to 1000 names, 2 items per name, can be registered.

n Transferring mobile phone data







Select the group to transfer to.



To overwrite data, touch

To add to existing data, touch



Transfer will begin. If you wish to cancel the transfer before it is finished, touch Cancel .

Transfer is complete when "Transfer completed" is displayed.

If "Transfer failed" is displayed, restart the process from the beginning.

n Registering by input



STEP 2 Touch on the "Information" screen.

STEP 3 Touch settings on the "Telephone" screen.

STEP 4 Touch on the "Settings" screen.



Touch Register in the "Phone Book" section.

STEP 6 Choose the switch to register.





Name : Input the name on the "Name" screen.

and TEL2:
Input the number(s) on the "Telephone Number" screen. When you touch OK, the "Select Icon" screen will appear.
Choose the desired

Mobile phone2
| Mobile phone2
| Home
| Work
| Other

icon.

Group: Select the desired group from the "Select Group" screen. (No Group, 01 - 09)

Voice Rec. : Select the desired phone number and touch REC to record a voice tag.

To play the voice tag, touch PLAY. To

touch PLAY. To delete the voice tag, touch Delete.

STEP 7 Once input is complete, touch OK.

n Adding call history data to a registered entry



STEP 2 Touch on the "Information" screen.

STEP 3 Touch Call Log on the "Telephone" screen.

STEP 4 Choose the desired number from the list.

To choose from the incoming call history, touch and select the desired number.



Touch Add to

STEP 6 Choose the phone book entry to be added to.

STEP 7 Check the data to be added, and touch OK.

n Editing phone book data

- STEP 1 Press
- STEP 2 Touch on the "Information" screen.
- STEP 3 Touch settings on the "Telephone" screen.
- STEP 4 Touch on the "Settings" screen.
- Touch In the "Phone Book" section of the "Phone Book Management" screen.
- STEP 6 Choose the data to edit.
- STEP 7 Choose the switch to edit.
- STEP 8 After editing, touch OK.

n Deleting phone book data

- STEP 1 Press .
- STEP 2 Touch on the "Information" screen.
- STEP 3 Touch settings on the "Telephone" screen.
- STEP 4 Touch on the "Settings" screen.
- Touch Delete in the "Phone Book" section of the "Phone Book Management" screen.
- STEP 6 Select the data to delete.
- STEP 7 A confirmation message will be displayed. If everything is correct, touch research.

n To delete all data

Follow the steps for "Deleting phone book data" until "STEP 5". In the "Phone Book" section of the "Phone Book Management" screen, touch Delete all data within a group, touch Group Data , and select the group to delete. To delete all contact data, touch AllContact Data . Check that everything is correct, and touch Yes .

n Registering/Editing/Deleting from the phone book

You can register data in the phone book, edit registered data, and delete items.



STEP 2 Touch on the "Information" screen.

STEP 3 Touch Phone on the "Telephone" screen.

STEP 4 To register data, touch Register on the "Phone Book" screen.

To delete all data, touch Delete All .

To delete or edit specific data, select the data to delete/edit, and touch

Delete to delete, or Edit to edit.

n The phone book

The method for transferring phone book data from the phone to the system varies with phone model. See the phone's manual.

Changing the phone book group name settings

n Registering a group name



- STEP 2 Touch on the "Information" screen.
- STEP 3 Touch settings on the "Telephone" screen.
- STEP 4 Touch on the "Settings" screen.
- STEP 5 Touch Register in the "Group Name" section of the "Phone Book Management" screen.
- STEP 6 Select the group to register ("01" "19").



Select the switch to be edited.

- :The below screen will be displayed. Select the desired icon.
- Name: Input the name on the "Name" screen.



STEP 8 Once editing is complete, touch OK

n Deleting a group name

STEP 1 Press

STEP 2 Touch on the "Information" screen.

STEP 3 Touch settings on the "Telephone" screen.

STEP 4 Touch on the "Settings" screen.

STEP 5 Touch Delete in the "Group Name" section of the "Phone Book Management" screen.

Step 6 Select the group name to delete, and a confirmation message will be displayed.

STEP 7 If everything is correct, touch Yes.......

n To delete all data

Follow the steps for "Deleting phone book data" until to "STEP 5". In the "Phone Book" section of the "Phone Book Management" screen, touch Confirmation message will be displayed. If everything is correct, touch Yes.

Deleting the history



STEP 2 Touch on the "Information" screen.

STEP 3 Touch Callog on the "Telephone" screen.

STEP 4 Select the data to delete from the list.

To delete data from the incoming call history, touch and select the data to delete.



Touch Delete.

STEP 6 Check that everything is correct, and touch Yes


n To delete all data

Follow the steps for "Deleting a group name" until "STEP 4". Touch Outgoing Calls" screen. To delete all incoming call history data, touch outgoing Calls. Check that everything is correct, and touch Outgoing Calls.

Changing the security settings

You can disable certain hands-free system functions. Use the security settings when you do not wish other people to see the registered data, for example when having the vehicle valet parked at a hotel.

To enable or disable security, the security code (4 digits) is required. The default code is "0000". Be sure to change the security code before use.



message will appear.

STEP 8 If everything is correct, touch I



n Enabling security

STEP 1 Press .

STEP 2 Touch on the "Information" screen.

STEP 3 Touch settings on the "Telephone" screen.

STEP 4 Touch on the "Settings" screen.

STEP 5 Touch ON in the "Phone Book Lock" section of the "Phone Book Lock" screen.

STEP 6 Input the security code, and touch OK.

n Setting the security code to default

STEP 1 Press .

STEP 2 Touch on the "Information" screen.

STEP 3 Touch settings on the "Telephone" screen.

STEP 4 Touch on the "Settings" screen.

STEP 5 Touch Default on the "Phone Book Lock" screen.

Input the security code on the "Security Code" screen, and touch

OK. A confirmation message will appear.

STEP 7 If everything is correct, touch Yes......

n If "Phone Book Lock" is set

If the security code is input and "Phone Book Lock" is set, the following functions are locked:

- 1 Display of the phone book screen and transferring, registering, editing and deleting the phone book data.
- 1 Display of the speed dial screen, registering, deleting the speed dial and speed dialing.
- 1 Display of the other party's name for calls being received or made.
- 1 Display of the dialed numbers screen and incoming call screen, deleting the dialed numbers and received numbers
- 1 Display of the phone information screen.
- 1 Changing the security code.

The speed dial screen is not displayed while driving.

n When changing the security code

- 1 Be sure to choose a number difficult for strangers to guess.
- 1 Do not forget the security code. Even your Lexus dealer will be unable to disable the security. If you do forget the code, initialize all personal data. (→P. 245)

Setting a Bluetooth[®] phone

n Selecting a Bluetooth® phone

If multiple Bluetooth[®] phones are registered, follow the procedure below to select the Bluetooth[®] phone to be used. You may only use one phone at a time.



STEP 2 Touch on the "Information" screen.

STEP 3 Touch settings on the "Telephone" screen.



Touch 🔝.



Select the phone to be used, and touch **OK**.

If no phones are registered, "Empty" will be displayed.

If "Bluetooth* connection successful" is displayed, registration was successful.

If another Bluetooth[®] phone is already connected, a confirmation message is displayed. Touch

^{*:} Bluetooth is a registered trademark of Bluetooth SIG. Inc.

${\operatorname{\textbf{n}}}$ Displaying Bluetooth ${\operatorname{\textbf{@}}}$ information

You can check the device address and device name.



STEP 2 Touch on the "Information" screen.

STEP 3 Touch Settings on the "Telephone" screen.

STEP 4 Touch 🔝 on the "Settings" screen.

STEP 5 On the "Select Telephone" screen, select the desired phone and touch Information.



To change the device name, touch Change in the "Device Name" section, and input the name on the "Name" screen (max. 20 characters).

n To change the Bluetooth $^{ extstyle ext$

You can change the device name and passkey.



STEP 2 Touch on the "Information" screen.

STEP 3 Touch settings on the "Telephone" screen.

STEP 4 Touch on the "Settings" screen.



To change the device name, touch Change in the "Device Name" section, and input the name on the "Name" screen (max. 20 characters).

To change the passkey, touch Change in the "Passkey" section, and input 4 - 8 digits on the "Passkey" screen.

n Setting the Bluetooth® settings to default



STEP 2 Touch on the "Information" screen.

STEP 3 Touch settings on the "Telephone" screen.

STEP 4 Touch on the "Settings" screen.

Touch Default on the "Bluetooth* Settings" screen, and a confirmation message will be displayed.

STEP 6 If everything is correct, touch Yes

^{*:} Bluetooth is a registered trademark of Bluetooth SIG. Inc.

n To delete the Bluetooth $^{ extbf{R}}$ settings

STEP 1 Press .

STEP 2 Touch on the "Information" screen.

STEP 3 Touch Settings on the "Telephone" screen.

STEP 4 Touch on the "Settings" screen.

STEP 5 Touch Delete in the "Bluetooth* Telephone" section of the "Bluetooth* Settings" screen.

STEP 6 On the "Delete Telephone" screen, select the phone to delete.

To check the device address, touch Information.

STEP 7 If you touch OK, a confirmation message is displayed. If everything is correct, touch Yes.

^{*:} Bluetooth is a registered trademark of Bluetooth SIG. Inc.